



PT3E-05219

Optical Interferometric Gas Concentration Meter

FI-8000

Operating Manual (PT3-052)

RIKEN KEIKI Co., Ltd.

2-7-6 Azusawa, Itabashi-ku, Tokyo, 174-8744, Japan

Phone : +81-3-3966-1113

Fax : +81-3-3558-9110

E-mail : intdept@rikenkeiki.co.jp

Web site : <https://www.rikenkeiki.co.jp/>

<Contents>

1	Outline of the Product	2
1-1.	Preface	2
1-2.	Purpose of use	2
1-3.	Definition of DANGER, WARNING, CAUTION and NOTE	3
2	Important Notices on Safety	4
2-1.	Danger cases	4
2-2.	Warning cases	6
2-3.	Precautions	7
2-4.	Safety Information	8
3	Product Components	10
3-1.	Main unit and standard accessories	10
3-2.	Names and functions for each part	13
4	How to Use	15
4-1.	Before using the concentration meter	15
4-2.	Preparation for start-up	15
4-3.	Basic operating procedures	19
4-4.	How to start the concentration meter	20
4-5.	Measurement method (measuring mode)	22
4-6.	Manual Memory	24
4-7.	Measuring Gas/Range Detail Display	25
4-8.	Reference gas calibration	26
4-9.	Setup mode	28
4-10.	Recording measurement mode (pump suction type only)	35
4-10.	How to exit	41
5	Operations and Functions	42
5-1.	CAUTION display	42
5-2.	ERROR display	44
6	Maintenance	45
6-1.	Maintenance intervals and items	45
6-2.	Calibration	46
6-3.	How to clean	46
6-4.	Parts replacement	47
7	Storage and Disposal	48
7-1.	Procedures to store the concentration meter or leave it for a long time	48
7-2.	Procedures to use the concentration meter again	48
7-3.	Disposal of products	49
8	Troubleshooting	50
9	Product Specifications	53
9-1.	List of specifications	53
9-2.	List of accessories	55
10	Definition of Terms	56
11	Detection Principle	57
	Measuring Gas Specifications by Type	58

1

Outline of the Product

1-1. Preface

Thank you for choosing our optical interferometric gas concentration meter FI-8000. Please check that the model number of the product you purchased is included in the specifications on this manual.




This manual explains how to use the concentration meter and its specifications. It contains information required for using the concentration meter properly. Not only the first-time users but also the users who have already used the product must read and understand the operating manual to enhance the knowledge and experience before using the concentration meter.

1-2. Purpose of use

This product is a portable concentration meter designed to measure concentration or density of gases, such as halothane in oxygen and methyl bromide in the air.


The measuring gases and ranges vary by the type of FI-8000 you purchased. Check the type again before use and perform gas measurement properly in accordance with purposes (see "Measuring Gas Specifications by Type" at the end of this manual for identifying the type).

1-3. Definition of DANGER, WARNING, CAUTION and NOTE

 DANGER	This message indicates that improper handling may cause serious damage on life, health or assets.
 WARNING	This message indicates that improper handling may cause serious damage on health or assets.
 CAUTION	This message indicates that improper handling may cause minor damage on health or assets.
NOTE	This message indicates advice on handling.

1-4. Method of confirmation for Standards and Explosion proof specification

This instrument has some specification depends on standard and explosion proof certificate. Please confirm the detector specification before using. Please refer Declaration of Conformity that is at the end of this manual if you have CE/UKCA marking type. You can confirm instrument specification to see name plate as follows.



Type name plate

2

Important Notices on Safety

2-1. Danger cases



DANGER

About explosion-proof

- When using this gas detector in a hazardous area, take the following countermeasures for preventing dangers resulting from electrostatic charges.
 - (1) Wear anti-static clothes and conductive shoes (anti-static work shoes).
 - (2) For indoor use, use the gas detector while standing on a conductive work floor (with a leakage resistance of 10 MΩ or less).
- **【FI-8000】**The battery units that can be connected are the BUL-8000(F)(TC21066), BUL-8000 (F1)(TC21067), or BUD-8000(F)(TC21065).
- **【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】**The main unit that can be connected is FI-8000(TC21064) only.
- **【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】**Do not attach and remove the battery unit in a hazardous location.
- **【BUL-8000(F), BUL-8000(F1)】**Charging has to be done with the dedicated AC adaptor in non-hazardous area.
- **【BUL-8000(F), BUL-8000(F1)】**The temperature should be between 0degree C and +40degree C.
- **【BUD-8000(F)】**Do not attach and remove batteries in the dry battery unit in a hazardous location.
- **【BUD-8000(F)】**Use specified AA alkaline batteries (LR6 TOSHIBA) for the dry battery unit.
- The specifications of the gas detector are as follows:

Sensor circuit	: Allowable voltage of 4.95 V, allowable current of 1.12 A, and allowable power of 1138 mW
Pump circuit	: Allowable voltage of 4.95 V, allowable current of 0.834 A, and allowable power of 853 mW
Buzzer circuit	: Allowable voltage of 4.95 V, allowable current of 0.431 A, and allowable power of 441 mW
Main circuit	: Allowable voltage of 4.95 V, allowable current of 0.717 A, and allowable power of 733 mW
Backup circuit	: 3.0 VDC, 10 μA
Ambient temperature	: -20degree C to +50degree C



DANGER

About explosion-proof

- The specifications of the BUL-8000(F), BUL-8000(F1) are as follows:
 - Sensor circuit : Maximum voltage of 4.25 V, maximum current of 1.12 A, and maximum power of 901 mW
 - Pump circuit : Maximum voltage of 4.25 V, maximum current of 0.768 A, and maximum power of 618 mW
 - Buzzer circuit : Maximum voltage of 4.25 V, maximum current of 0.410 A, and maximum power of 330 mW
 - Main circuit : Maximum voltage of 4.25 V, maximum current of 0.653 A, and maximum power of 526 mW
 - Battery charging contact : Allowable current of 250 VAC 50/60Hz
 - Ambient temperature : -20degree C to +50degree C
- The specifications of the BUD-8000(F) are as follows:
 - Sensor circuit : Maximum voltage of 4.95 V, maximum current of 1.12 A, and maximum power of 1138 mW
 - Pump circuit : Maximum voltage of 4.95 V, maximum current of 0.834 A, and maximum power of 853 mW
 - Buzzer circuit : Maximum voltage of 4.95 V, maximum current of 0.431 A, and maximum power of 441 mW
 - Main circuit : Maximum voltage of 4.95 V, maximum current of 0.717 A, and maximum power of 733 mW
 - Power supply : 4.5 VDC, 150 mA (LR6 3 pcs)
 - Ambient temperature : -20degree C to +50degree C
- Make sure that the product model on the nameplate is correct.
Inappropriate combinations of models deviate from the range of explosion-proof certification.
- The nameplate shows the followings as well as the product model.
 - Product model : Main unit: FI-8000
Lithium ion battery unit: BUL-8000 (F), BUL-8000(F1)
Dry battery unit: BUD-8000 (F)
 - Explosion proof class : 【FI-8000】Ex ia IIC T4
【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】 Ex ia IIC T4
 - Ambient temperature : -20 to 50°C
 - Charging terminal rating : 【BUL-8000(F), BUL-8000(F1)】Allowable voltage AC250V 50/60Hz
- Warnings : 【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】
Inhibit to take off battery unit in non-hazardous area.
- Manufacturer : RIKEN KEIKI Co., Ltd.
- IP protection class: IP20

About use

- To measure a harmful or explosive gas, take a measure to prevent diffusion of the discharged gas such as attaching a gas sampling bag to the gas outlet (GAS OUT).
- The purpose of the specification targeting anesthetic gas (halothane, isoflurane, sevoflurane, desflurane and enflurane) for measurement is to measure the gas concentration of volatile anesthetic which occurs from anesthetic vaporizer during the manufacturing or inspection. Please do not use it for anesthetic gas concentration in the administration to human and animals nor anesthetic gas measurement for interference gas including laughter gas and aspirated air.
- Before using our product for measurement, please confirm that the measurement gas type is selected correctly.
- In case there are interference gases which are not selected as a measurement gas, you will not get the correct measurement, so please do not use it in that circumstance.

2-2. Warning cases



WARNING

Sampling point pressure

- The concentration meter is designed to draw gases around it under the atmospheric pressure. If excessive pressure is applied to the gas inlet (GAS IN) and outlet (GAS OUT) of the concentration meter, measuring gases may leak out from its inside and may cause dangerous conditions. Be sure that excessive pressure is not applied to the concentration meter while used.
- Do not connect the gas sampling hose directly to a location with a pressure higher than the atmospheric pressure. The internal piping system may be damaged.

Reference gas calibration in the atmosphere

- When the reference gas calibration is performed in the atmosphere, check the atmosphere for freshness before beginning the calibration. If interference gases (other than measuring and base gases) exist, the adjustment cannot be performed properly, thus leading to dangers when the gas leaks.

Battery level check

- Before use, check that there remains sufficient battery power. When the concentration meter is used for the first time or is not used for a long period, the batteries may be exhausted. Either fully charge the batteries or replace them with new ones before use.
- If a battery error occurs, measurement cannot be performed. If the error message is displayed during use, turn off the power and promptly replace or charge the batteries in a non-hazardous area.

Others

- Do not draw a high-concentration gas beyond the measuring range. Accurate readings cannot be obtained.
- Do not throw the concentration meter into fire.
- Do not block the buzzer sound opening. No buzzer sound can be heard.
- Do not remove the battery unit while the power is on.
- Use dry batteries of the specified ratings for the concentration meter.

2-3. Precautions



CAUTION

Do not measure gases that contain interference gases.

- If a measuring gas contains an interference gas (other than measuring and base gases), accurate readings cannot be obtained.
Do not measure gases that contain interference gases.

The gas inlet and outlet should be at the atmospheric pressure.

- Keep the gas inlet and outlet at the atmospheric pressure.

Do not use the concentration meter where it is exposed to oil, chemicals, etc. Do not submerge the concentration meter under water on purpose.

- Do not use in a place where the concentration meter is exposed to liquids such as oil and chemicals.
- The concentration meter, being compliant to IP67, is not water-pressure-resistant. Do not use the concentration meter where a high water pressure is applied to it (under a faucet, shower, etc.) or submerge it under water for a long time. The concentration meter is water-proof only in fresh water and running water, and not in hot water, salt water, detergent, chemicals, human sweat, etc.
- The gas inlet and outlet are not water-proof. Be careful not to let water such as rainwater get into these parts. Because this may cause trouble and gas cannot be measured.
- Do not place the concentration meter where water or dirt gets accumulated. The concentration meter placed at such a location may malfunction due to water or dirt that gets into the buzzer opening, gas inlet, etc.
- Note that drawing in dirty water, dust, metallic powder, etc. will significantly deteriorate the sensor sensitivities. Be careful when the concentration meter is used in an environment where these elements exist.

Do not use the concentration meter in a place where the temperature drops below -20°C or rises over 50°C .

- The operating temperature of the concentration meter is -20 to 50°C . Do not use the concentration meter at higher temperatures, humidities and pressures or at lower temperatures than the operating range.
- Avoid long-term use of the concentration meter in a place exposed to radiant heat (infrared rays emitted from a high-temperature object) or direct sunlight.
- Do not store the concentration meter in a sun-heated car.

Observe the operating restrictions to prevent condensation inside the concentration meter or gas sampling hose.

Condensation formed inside the concentration meter or gas sampling hose causes clogging or gas adsorption, which may disturb accurate gas measurement. Thus, condensation must be avoided. In addition to the operating environment, carefully monitor the temperature/humidity of the sampling point to prevent condensation inside the concentration meter or gas sampling hose. Please observe the operating restrictions.

Do not use a transceiver near the concentration meter.

- Radio wave from a transceiver near the concentration meter may disturb readings. If a transceiver or other radio wave transmitting device is used, it must be used in a place where it disturbs nothing.
- Do not use the concentration meter near a device that emits strong electromagnetic waves (high-frequency or high-voltage devices).

Never fail to perform a regular maintenance.

Never fail to perform a regular maintenance to ensure safety. Continuing to use the concentration meter without performing maintenance will result in inaccurate gas measurement.

Others

- Operate the concentration meter using only the procedures described in this operating manual.
- Do not drop or give shock to the concentration meter. The water-proof performance and accuracy may be deteriorated.
- Do not use the concentration meter while charging it.

2-4. Safety Information

The FI-8000 is an optical interferometer which is used for measuring gas concentration or calorie of flammable gases in hazardous location.

It has two different suction styles, one is manual aspirating with squeezing a rubber bulb and other is automatic suction by an internal micro pump.

The battery can be selected either Li-ion battery or alkaline dry battery.

Li-ion battery unit is called BUL-8000(F), BUL-8000(F1) and alkaline dry battery unit is called BUD-8000(F).

The battery unit structured in a way, that even the end user is possible to replace it.

Specification for safety

- Ex ia IIC T4 Ga

-  II 1 G Ex ia IIC T4 Ga

- Ambient temperature range for use : -20°C to +50°C

- Ambient temperature range during battery charging : 0°C to +40°C

Electrical data

- Power supply of Li-ion battery unit : BUL-8000(F), BUL-8000(F1)

Two parallel connected Li-ion cells used in battery pack BP-8000 are from type Maxell INR18650PB1 or SDI INR18650-15M or SONY US18650VT3. Um=250V.

- Power supply of dry battery unit : BUD-8000(F)

Powered by three series AA size alkaline batteries, model LR6 by TOSHIBA.

Certificate numbers

- IECEx Certificate number : IECEx PRE 14.0061

- ATEX Certificate number : Presafe 14 ATEX 5711X

- UK Type Examination Certificate : DNV 22 UKEX 22578X

List of standards

- IEC 60079-0:2017

- EN IEC 60079-0:2018

- BS EN IEC 60079-0:2018

- IEC 60079-11:2011

- EN60079-11:2012

- BS EN 60079-11:2012

Specific conditions of "X"-mark:

Regarding ATEX specification, the measuring function according to Annex II paragraph 1. 5. 5 of the Directive is not covered by this EU-type examination.

It shall comply with the requirements from the relevant European harmonized standards which provide guidance on the performance of gas detection equipment and safety devices.

The measuring function according to schedule 1, paragraph 24 of the Regulation is not covered in this UK-type examination. It shall comply with the requirements from the relevant UK

Designated Standards which provide guidance on the performance of gas detection equipment.

WARNING

- DO NOT CHARGE IN HAZARDOUS LOCATION.

- DO NOT CHARGE IT EXCEPT BY GENUINE CHARGER.

- DO NOT REPLACE BATTERY UNIT IN HAZARDOUS LOCATION.

- DO NOT REPLACE DRY BATTERIES IN HAZARDOUS LOCATION.

- DO NOT ATTEMPT TO DISASSEMBLE OR ALTER THE INSTRUMENT.

- USE ONLY WITH CONNECTED ALKALINE AA BATTERY, TYPE LR6

MANUFACTURED BY TOSHIBA.

INST. No. 0 0 0 0 0 0 0 0 0 0

A B C D E

A: Manufacturing year (0-9)

B: Manufacturing month (1-9,XYZ for Oct.-Dec.)

C: Manufacturing lot

D: Serial number

E: Code of factory



RIKEN KEIKI Co., Ltd.

2-7-6 Azusawa, Itabashi-ku, Tokyo, 174-8744, Japan

Phone : +81-3-3966-1113

Fax : +81-3-3558-9110

E-mail : intdept@rikenkeiki.co.jp



Web site : <https://www.rikenkeiki.co.jp>

3

Product Components

3-1. Main unit and standard accessories

After opening the package, check the main unit and accessories.
If anything in the following list is not included, contact RIKEN KEIKI.

<p><Main Unit></p> <p>FI-8000 main unit</p>  <p>Dry battery unit or Lithium ion battery unit</p>	<p><Standard Accessories></p> <ul style="list-style-type: none"> • Alkaline dry battery: 3 (for dry battery unit) • AC power charger: 1 (for lithium ion battery unit) • Gas sampling hose: 1 • Shoulder strap: 1 • Handy aspirator: 1 (manual draw-in type only) • Absorbing tube (contains calcium chloride) and absorbing tube fixing belt (anesthetic gas specification type only) • Operating manual • Measuring gas specifications (attached when measuring gases are not included in "Measuring Gas Specifications by Type" at the end of this manual) • Product warranty 
----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------



DANGER

About explosion-proof

- When using this gas detector in a hazardous area, take the following countermeasures for preventing dangers resulting from electrostatic charges.
 - (1) Wear anti-static clothes and conductive shoes (anti-static work shoes).
 - (2) For indoor use, use the gas detector while standing on a conductive work floor (with a leakage resistance of 10 MΩ or less).



DANGER

- **【FI-8000】**The battery units that can be connected are the BUL-8000(F)(TC21066), BUL-8000 (F1)(TC21067) or BUD-8000(F)(TC21065).
- **【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】**The main unit that can be connected is FI-8000(TC21064) only.
- **【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】**Do not attach and remove the battery unit in a hazardous location.
- **【BUL-8000(F), BUL-8000(F1)】**Charging has to be done with the dedicated AC adaptor in non-hazardous area.
- **【BUL-8000(F), BUL-8000(F1)】**The temperature should be between 0degree C and +40degree C.
- **【BUD-8000(F)】**Do not attach and remove batteries in the dry battery unit in a hazardous location.
- **【BUD-8000(F)】**Use specified AA alkaline batteries (LR6 TOSHIBA) for the dry battery unit.
- The specifications of the gas detector are as follows:
 - Sensor circuit : Allowable voltage of 4.95 V, allowable current of 1.12 A, and allowable power of 1138 mW
 - Pump circuit : Allowable voltage of 4.95 V, allowable current of 0.834 A, and allowable power of 853 mW
 - Buzzer circuit : Allowable voltage of 4.95 V, allowable current of 0.431 A, and allowable power of 441 mW
 - Main circuit : Allowable voltage of 4.95 V, allowable current of 0.717 A, and allowable power of 733 mW
 - Backup circuit : 3.0 VDC, 10 μ A
 - Ambient temperature : -20degree C to +50degree C
- The specifications of the BUL-8000(F), BUL-8000(F1) are as follows:
 - Sensor circuit : Maximum voltage of 4.25 V, maximum current of 1.12 A, and maximum power of 901 mW
 - Pump circuit : Maximum voltage of 4.25 V, maximum current of 0.768 A, and maximum power of 618 mW
 - Buzzer circuit : Maximum voltage of 4.25 V, maximum current of 0.410 A, and maximum power of 330 mW
 - Main circuit : Maximum voltage of 4.25 V, maximum current of 0.653 A, and maximum power of 526 mW
 - Battery charging contact : Allowable current of 250 VAC 50/60Hz
 - Ambient temperature : -20degree C to +50degree C
- The specifications of the BUD-8000(F) are as follows:
 - Sensor circuit : Maximum voltage of 4.95 V, maximum current of 1.12 A, and maximum power of 1138 mW
 - Pump circuit : Maximum voltage of 4.95 V, maximum current of 0.834 A, and maximum power of 853 mW
 - Buzzer circuit : Maximum voltage of 4.95 V, maximum current of 0.431 A, and maximum power of 441 mW
 - Main circuit : Maximum voltage of 4.95 V, maximum current of 0.717 A, and maximum power of 733 mW
 - Power supply : 4.5 VDC, 150 mA (LR6 3 pcs)
 - Ambient temperature : -20degree C to +50degree C
- Make sure that the product model on the nameplate is correct.
Inappropriate combinations of models deviate from the range of explosion-proof certification.
- The nameplate shows the followings as well as the product model.
 - Product model : Main unit: FI-8000
Lithium ion battery unit: BUL-8000 (F), BUL-8000(F1)
Dry battery unit: BUD-8000 (F)
 - Explosion proof class : **【FI-8000】**Ex ia IIC T4
【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】 Ex ia IIC T4
 - Ambient temperature : -20 to 50°C
 - Charging terminal rating : **【BUL-8000(F), BUL-8000(F1)】**Allowable voltage AC250V 50/60Hz
- Warnings : **【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】**
Inhibit to take off battery unit in non-hazardous area.
- Manufacturer : RIKEN KEIKI Co., Ltd.
- IP protection class: IP20


NOTE

Connect either the lithium ion battery unit BUL-8000(F), BUL-8000(F1) or dry battery unit BUD-8000(F).

Check the model of the battery unit with the nameplate affixed to the unit.


A nameplate indicating a compatible model is affixed to the battery unit to avoid using the gas monitor in combination with a wrong unit.

Check this information and use a correct combination.



3-2. Names and functions for each part

<Outline Drawing> (Main Unit)



(1)	LCD display	Displays a measuring gas name, concentration, error, etc.
(2)	Buzzer sound opening	Emits a buzzer sound at power-on/off or error occurrence. (Do not block it.)
(3)	Alarm LED arrays	The lamp blinks in response to error occurrence.
(4)	Infrared communication port	Used to carry out data communications with a PC in data logger mode.
(5)	REF CAL switch [▲ switch]	Used to perform reference gas calibration. [Used to enter numerical values or move a screen.]
(6)	REC. switch [▼ switch]	Used to save measurement results in the measuring mode. [Used to enter numerical values or move a screen.]
(7)	DISP switch [ESC switch]	Displays detailed information such as a range of measuring gas. [Used to stop processing and to do others.]

(8)	POWER switch [ENTER switch]	Turns ON/OFF the power. [Used to make a selection in the setup and recording measurement modes.]
(9)	Gas inlet	Draws in a gas (do not block it). The gas sampling hose is connected.
(10)	Gas outlet	Discharges a gas drawn into the concentration meter (do not block it). (A handy aspirator is attached for the handy aspirator specification type.)
(11)	Battery cover	Opened or closed when replacing dry batteries.
(12)	Battery cover fixing screw	Fixes the battery cover.
(13)	Battery unit screws	Loosened to detach and replace the battery unit.


- The switches and descriptions in [] are for the setup and recording measurement modes.



CAUTION

- Do not jab the buzzer sound opening with a sharp-pointed item. The unit may malfunction or get damaged, allowing water or foreign matter, etc. to get inside.
- Do not remove the panel sheet on the surface. The water-proof and dust-proof performances will be deteriorated.
- Do not affix a label or the like on the infrared communication port. Infrared communications can no longer be conducted.

<LCD Display> (Measuring mode)



(1)	Battery level icon	Displays the battery level. See the information below for the meanings of battery level icons.
(2)	Unit	Displays a unit of gas concentration.
(3)	Measuring gas concentration display	Displays the gas concentration as numeric output.
(4)	Measuring gas name	Displays the measuring gas name.

NOTE

- The meanings of battery level icons are as follows:
 : Sufficient/ : Low/ : Needs replacement (charging)
- If the battery level further drops, the inside of the battery icon starts to blink ().

4

How to Use

4-1. Before using the concentration meter

Not only the first-time users but also the users who have already used the concentration meter must follow the operating precautions.

Ignoring the precautions may damage the unit, resulting in inaccurate gas measurement.

4-2. Preparation for start-up

Before starting gas measurement, read and understand the following precautions. Ignoring these precautions may prevent correct gas measurement.

- Check that the battery level is sufficient.
- Check that there is no bend or hole in the gas sampling hose.
- Check that the filter in the gas sampling probe is free of dust or clogging.
- Check that the main unit and gas sampling hose are connected properly.
- Check that the main unit and handy aspirator are connected properly (the handy aspirator specification type only).



DANGER

- 【BUL-8000(F), BUL-8000(F1), BUD-8000(F)】Do not attach and remove the battery unit in a hazardous location.
- 【BUL-8000(F), BUL-8000(F1)】Charging has to be done with the dedicated AC adaptor in non-hazardous area.
- 【BUL-8000(F), BUL-8000(F1)】The temperature should be between 0degree C and +40degree C.
- 【BUD-8000(F)】Do not attach and remove batteries in the dry battery unit in a hazardous location.
- 【BUD-8000(F)】Use specified AA alkaline batteries (LR6 TOSHIBA) for the dry battery unit.

<Attaching Batteries> (When the dry battery unit BUD-8000(F) is used)

When the concentration meter is used for the first time, or when the battery level is low, attach new AA alkaline batteries.



CAUTION


<Replacement>

- Turn off the power of the concentration meter before replacing the batteries.
- Replace the batteries in a non-hazardous area.
- Replace all of the three batteries with new ones at one time.
- Pay attention to the polarities of the batteries.
- If the battery cover fixing screw is not completely tightened, the dry batteries may drop off or water may get in through the clearance.
Water may also get in if a minute foreign substance is caught beneath the battery unit.


<Batteries>

- Use AA alkaline batteries. Rechargeable batteries cannot be used.
- If the concentration meter is not used for a long time, store it after removing the batteries.

- (1) Using a flathead screwdriver or coin, turn the battery cover fixing screw counterclockwise to open the battery cover.
- (2) Paying attention to the polarities of batteries, replace all the three batteries with new ones.



- (3) Close the battery cover and tighten the battery cover fixing screw.



<Charging Batteries> (When the lithium ion battery unit BUL-8000(F), BUL-8000(F1) is used)

When the concentration meter is used for the first time, or when the battery level is low, be sure to use the accessory AC powered charger to charge the batteries.



DANGER


- Use the dedicated AC powered charger.
- Charge the battery unit in a non-hazardous area.
- Charge the battery unit at ambient temperatures between 0 to +40°C.
- Do not use the concentration meter while charging it. Correct measurements cannot be obtained.
Furthermore, the batteries get deteriorated more quickly and may have shorter life.
- The charger is neither water-proof nor dust-proof. Do not charge the batteries while the concentration meter is wet.
- The AC powered charger is not explosion-proof.

- (1) Open the charging jack cover of the concentration meter.



CAUTION

Do not pull the charging jack cover too hard. It may get damaged.



- (2) Put the plug of the AC powered charger into the charging jack of the concentration meter.
- (3) Connect the AC powered charger to the wall electric outlet.
When charging is started, the charging indicator lamp lights up (red).
(Charging time: Three hours at the maximum until the batteries are fully charged)
- (4) When charging is completed, the charging indicator lamp goes off.
- (5) When charging is completed, disconnect the AC powered charger from the wall electric outlet.
- (6) Pull out the AC powered charger plug from the charging jack of the concentration meter and reattach the charging jack cover (rubber cap). Push the charging jack cover as far as it will go.



CAUTION

- Do not use the concentration meter with the charging jack cover detached. Dust or water may get into the concentration meter, causing it to malfunction.
- If the charging jack cover is not completely closed, water may get in from the power jack. The same thing occurs if a minute foreign substance is caught beneath the knob.
- Disconnect the AC powered charger plug from the charging jack while it is not in use.

NOTE

- During charging, the battery unit may get hot, but this is not an abnormality.
- The temperature of the concentration meter is high immediately after charging is completed. Let it stand for 10 minutes or more before using it. Otherwise, correct measurements may not be obtained.
- When fully charged batteries are recharged, the charging indicator lamp does not go on.

<Releasing and Attaching the Battery Unit>

- (1) Loosen the two battery unit screws.
(They need not be completely detached.)
- (2) Detach the battery unit.
- (3) Attach a new battery unit.


NOTE

Make sure that the battery unit is installed in correct orientation by checking the locations of the connection terminal and projection portions.


- (4) Securely tighten the two battery unit screws.

**CAUTION**

- Turn off the power of the concentration meter before replacing the battery unit.
- Detach and reattach the battery unit in a non-hazardous area.
- If the battery unit screw is not completely tightened, the battery unit may drop off or water may get in through the clearance.
Also, if a minute foreign substance is caught in the clearance, water may get in.
- Do not damage the rubber seal.
- To maintain the water-proof and dust-proof performances, it is recommended to replace the rubber seal every two years, whether or not it has an abnormality.




Battery unit screws



Bottom of concentration meter


<Connecting the Gas Sampling Hose>

- Connect the sampling hose securely to the gas inlet (GAS IN) of the concentration meter.
- To use an absorbing tube, connect tubes to the gas inlet (GAS IN) of the concentration meter in the following order: relay tube, absorbing tube and then gas sampling hose.
- To use the handy aspirator specification type, connect the handy aspirator securely to the gas outlet (GAS OUT) of the concentration meter.

**CAUTION**

Use only the tubes specified by RIKEN KEIKI.

4-3. Basic operating procedures (measuring mode)



NOTE

The concentration meter provides various operating modes: "Measur<Measuring Mode>uring a specified gas continuously, "Setup mode" for changing a measuring gas, setting time, etc. and "Recording measurement mode (pump specification type only)" for measuring and recording at specified time intervals. The power-on method differs in each mode. See "4-7. Modes" for details.

4-4. How to start the concentration meter


<Start-up Procedures> (Measuring mode)

Keep the POWER switch pressed for three seconds or more.




All LCDs light up.
 Alarm lamp lights up.
 Buzzer sounds once. (Beep)


LCD




Self-diagnosis (battery level)
 Example: March 10, 2014 23:47
 OK (no problem)




Self-diagnosis (UV intensity)
 Example: OK (no problem)



Self-diagnosis (contrast)
 Example: OK (no problem)



Measuring mode
 Buzzer sounds twice. (Beep, beep)




CAUTION

After start-up, make the concentration meter draw the reference gas specified in the measuring gas specifications sufficiently from the gas inlet (GAS IN) before performing gas measurement. If the concentration meter does not read the reference calibration value specified in the measuring gas specifications, perform reference gas calibration (see "4-8. Reference gas calibration").

<Self-diagnosis Function at Start-up>


The concentration meter provides various operating modes: "Measuring mode" for measuring a specified gas continuously, "Setup mode" for changing a measuring gas, setting time, etc. and "Recording measurement mode (pump suction type only)" for measuring and recording at specified time intervals. The power-on method differs in each mode. See "4-7. Modes" for details.

The self-diagnosis function works automatically regardless of the way to turn on the power, and the self-diagnosis screen is displayed (see P.17 Start-up Procedures). If a problem is found in the battery level, UV intensity or contrast as a result of self-diagnosis, the concentration meter displays "LOW" in the lower part of the screen and sounds the buzzer.



Display example: Low contrast

If the problem found is a minor one, the concentration meter enters the measuring mode. However, the screen provides the normal and caution displays alternately.



Display example: Caution display for low contrast

If the problem found is a major one that prevents measurement, the concentration meter does not enter any mode and displays an error.



Display example: Contrast error




CAUTION

If a caution or error is displayed, promptly take an appropriate remedial measure to restore the normal condition. See "8. Troubleshooting" for caution and error details and remedial actions.

4-5. Measurement method (measuring mode)

The concentration meter provides the following display in the measuring mode.

Display example



<- Display example

Sevoflurane concentration: 7.43 vol%
 Base gas: Air
 Battery level: Sufficient

<Automatic Draw-in by Built-in Pump>

In the measuring mode, put the gas sampling hose close to the measurement location and take the reading.

<Manual Draw-in by Handy Aspirator>

In the measuring mode, put the gas sampling hose close to the measurement location and squeeze the handy aspirator two or three times to draw a gas. The reading fluctuates widely due to change in pressure while a gas is drawn. After drawing a gas, take the reading when it is stabilized.



DANGER

- Oxygen-deficient air or other gases may blow out from the gas exhausting outlet. Never inhale the air or gases.
- To measure a harmful or explosive gas, take a measure to prevent diffusion of the exhausted gas such as attaching a gas sampling bag to the gas outlet (GAS OUT).
- The purpose of the specification targeting anesthetic gas (halothane, isoflurane, sevoflurane, desflurane and enflurane) for measurement is to measure the gas concentration of volatile anesthetic which occurs from anesthetic vaporizer during the manufacturing or inspection. Please do not use it for anesthetic gas concentration in the administration to human and animals nor anesthetic gas measurement for interference gas including laughter gas and aspirated air.
- Before using our product for measurement, please confirm that the measurement gas type is selected correctly.
- In case there are interference gases which are not selected as a measurement gas, you will not get the correct measurement, so please do not use it in that circumstance.



WARNING

- The concentration meter is designed to draw gases around it under the atmospheric pressure. If excessive pressure is applied to the gas inlet and outlet (GAS IN, GAS OUT) of the concentration meter, measuring gases may leak out from its inside and may cause dangerous conditions. Be sure that excessive pressure is not applied to the inlets while the concentration meter is used.
- Do not connect the gas sampling hose directly to a location with a pressure higher than the atmospheric pressure. The internal piping system may be damaged.
- Do not draw a gas with a pressure higher than the atmospheric pressure. Accurate readings cannot be obtained.
- Before use, check that there remains sufficient battery power. When the concentration meter is used for the first time or is not used for a long period, the batteries may be exhausted. Either fully charge the batteries or replace them with new ones before use.
- If a battery error occurs, measurement cannot be performed. If the error message is displayed during use, turn off the power and promptly replace or charge the batteries in a non-hazardous area.
- Do not draw a high-concentration gas beyond the measuring range. Accurate readings cannot be obtained.
- Do not block the buzzer sound opening. No buzzer sound can be heard when an error is displayed.



CAUTION

- If the measured gas contains an interference gas (other than measuring and base gases), accurate readings cannot be obtained. Do not measure gases that contain interference gases.
- Keep the gas inlet and outlet at the atmospheric pressure.
- The concentration meter does not read normally unless a measuring and base gases are selected correctly. Check that the measuring and base gas names displayed on the screen agree with ones to be measured before use.

NOTE

- In a low-temperature environment, the operating time is shortened due to the battery performance property.
- At a low temperature, the response of the LCD display may get slow down.
- If a high-concentration gas is drawn, some gas may remain in the gas sampling hose due to adsorption in the hose, etc. After drawing a high-concentration gas, clean the concentration meter to remove the adsorbed gas (draw a reference gas and check that the reading becomes the reference calibration value).

Note that if reference gas calibration is performed while the cleaning is incomplete, the concentration meter will not be adjusted properly and thus correct measurement cannot be performed. In such a case, remove the gas sampling hose before performing reference gas calibration to avoid inaccurate adjustment.

<Points of attention in fumigation gases measurement>

FI-8000 might indicate different reading from true measuring concentration due to influence of carbon dioxide concentration variation. In order to reduce the influence of carbon dioxide concentration variation as much as possible, please operate the FI-8000 with below instructions.

In order to reduce the influence of carbon dioxide concentration variation as much as possible, carbon dioxide needs to be removed by pretreating prior to start measurement. Carbon dioxide removal filter (soda lime filter)^{*1} and Moisture removal filter (calcium chloride filter)^{*2} are used for this pretreatment.


*1) Carbon dioxide removal filter (soda lime filter)

It removes carbon dioxide. Moisture will be generated in a chemical reaction of carbon dioxide and soda lime.

*2) Moisture removal filter (calcium chloride filter)

It removes moisture that is generated by carbon dioxide removal filter.


At the beginning, Reference gas calibration should be done using carbon dioxide removal filter and moisture removal filter at the fumigation area that there is no fumigation gas (see "4-6. Reference gas calibration"). Once gas is introduced, start measurement that also should be done using both filters as soon as possible. Since carbon dioxide is being generated from objects, if a time interval causes, you might not have accurate reading due to carbon dioxide concentration variation.




**CAUTION**

- Filters are consumables. Please replace both filters periodically.
- Incorrect filter connection sequence can cause failure. The FI-8000 will suck the moisture which is generated from carbon dioxide removal filter.

<Correct use>




<Incorrect use>




4-6. Manual Memory

Any instantaneous value during measurement can be recorded. Up to 256 points of data can be recorded.

- (1) In the measuring mode, press the REC. switch (for about two seconds).




- (2) The buzzer blips and the time and instantaneous value at that time are recorded. The following screens are displayed on the concentration meter.



The concentration meter returns to the normal display of the measuring mode automatically.

NOTE


If the maximum data amount (256 points) is exceeded, the concentration meter displays "RECORD FULL" and rejects saving of further data. To save data newly, delete the saved data in the display/setting mode (see "4-8. Setup mode" for details).



4-7. Measuring Gas/Range Detail Display

The detailed information of measuring gas/range can be checked.

- (1) Press the DISP switch. The concentration meter displays the following screens in turn (the display content varies by the combination of measuring and base gases).




- (2) After displaying ten cycles, the normal display returns.




4-8. Reference gas calibration

Draw a specified reference gas from GAS IN. When the reading is stabilized, press the REF. CAL switch (for more than two seconds).



When the buzzer blips, release the REF. CAL switch. Reference gas calibration is now finished.




CAUTION

- Perform reference gas calibration under pressure and temperature/humidity conditions close to those in the operating environment.
- Perform reference gas calibration after the reading is stabilized.
- If there is a sudden temperature change of 15°C or more between the storage and operation locations, turn on the power of the concentration meter, leave it for about ten minutes in a similar environment to the operation location, and perform reference gas calibration before using it.
- After calibration, check that the concentration meter reads the reference calibration value (REF. CAL value) which is determined by the combination of measuring and base gases. See the measuring gas specifications for REF. CAL values.

NOTE

When an occurrence of zero drift is highly likely, the caution display "CHECK REF. CAL" is displayed. In this case, draw a specified reference gas and perform reference gas calibration (see the measuring gas specifications for reference gas).



4-9. Setup mode

This mode allows changing various displays and settings.

This mode can be entered by pressing the POWER switch and holding down the ▲/REF CAL switch while the power is turned OFF, or holding down the DISP switch in the measuring mode.

Every time the ▲ switch is pressed, various menu screens are displayed in turn.


Power ON

Press the POWER switch while holding down the ▲/REF CAL switch.
(This mode can be entered by holding down the DISP switch in the measuring mode.)



Setup mode

LCD




Start-up procedures

⇒ P19

Measuring gas setting

A measuring gas can be selected.



→ ENTER


Measuring gas setting

⇒ P28



Date/time setting

Set the date and time of the internal clock.



→ ENTER


Date/time setting

⇒ P29



Saved data display

Display the data recorded in the manual memory or recording measurement mode.



→ ENTER


Saved data display

⇒ P30



Saved data clear

Clear saved data.



→ ENTER


Saved data clear

⇒ P31




IrDA communication

Establish an infrared communication with a personal computer to perform various settings or data management. (The communication program is available as an optional accessory.)



Switch to measuring mode
Exit the setup mode and enter the measuring mode.




→ Switch to measuring mode
ENTER ⇒P32


<Measuring Gas Setting "1. SELECT GAS">

A measuring gas can be selected.

- (1) Press the ▲/▼ switch and select "1. SELECT GAS" from the setup menu.




- (2) When the ENTER switch is pressed, the currently set measuring gas, base gas, measuring range and other information are displayed as shown below (the displayed information varies by the selected measuring gas or range).



NOTE

When there is no need of changing the setting, press the ESC switch to return to the setup mode menu.

- (3) When the ENTER switch is pressed again, the SPE number (a number allocated to a combination of measuring and base gases, measuring range, etc.) in the upper right section of the screen blinks. Every time the ▲ or ▼ switch is pressed, the displayed SPE number changes.



- (4) Press the ENTER switch to confirm it. After a value is confirmed, the concentration meter returns to the setup mode menu automatically.


NOTE

Contact RIKEN KEIKI for a change or addition of selectable gases.


<Date/Time Setting "2. SET DATE/TIME">

The date and time of the internal clock can be set.

- (1) Press the ▲/▼ switch and select "2. SET DATE/TIME" from the setup mode menu.



- (2) When the ENTER switch is pressed, the set time is displayed. (Input example: January 20, 2014 23:47)



NOTE


When there is no need of changing the setting, press the ESC switch to return to the setup mode menu.

- (3) When the ENTER switch is pressed again, the input area blinks. Enter the year, month, day, hour, and minute in this order. Press the ▲/▼ switch to change the values and press the ENTER switch to confirm each value (24-hour notation is used).
- (4) When the ENTER switch is pressed to confirm a change of time (minute), the concentration meter returns to the setup mode menu automatically.


<Saved Data Display "3. VIEW SAVED DATA">

The data recorded in the manual memory or recording measurement mode is displayed.

- (1) Press the ▲/▼ switch and select "3. VIEW SAVED DATA" from the setup mode menu.




- (2) Press the ENTER switch to display the saved data.



NOTE

When there is no need of viewing the detailed information of saved data, press the ESC switch to return to the setup mode menu.

- (3) Press the ▲/▼ switch to display the data numbers in turn. When the ENTER switch is pressed to make a selection, the saved data number/time, measuring gas, range and other information are displayed in turn in the lower part of the screen (the displayed information varies by the selected measuring gas or range).




- (4) When the ESC switch is pressed, the concentration meter returns to the setup mode menu.


<Saved Data Clear "4. CLEAR SAVED DATA">

The data recorded in the manual memory or recording measurement mode can be deleted.

- (1) Press the ▲/▼ switch and select "4. CLEAR SAVED DATA" from the setup mode menu.




- (2) When the ENTER switch is pressed, a confirmation screen asking for permission to delete the saved data appears.



NOTE

- When there is no need of deleting saved data, press the ESC switch to return to the setup mode menu.
- When saved data clear is executed, all the data recorded up to that time will be deleted.

- (3) Press the ENTER switch. When deletion is completed, DATA CLEAR is displayed in the upper right section of the screen.




- (4) When the ENTER or ESC switch is pressed, the concentration meter returns to the setup mode menu.


<Switch to Measuring Mode "6. START MEAS.">

The measuring mode can be entered from the setup mode.

- (1) Press the ▲/▼ switch and select "6. START MEAS." from the setup menu.




- (2) When the ENTER switch is pressed, a confirmation screen asking for permission to enter the measuring mode appears.



NOTE

When there is no need of entering the measuring mode, press the ESC switch to return to the setup mode menu.

- (3) When the ENTER switch is pressed, the concentration meter enters the measuring mode.




4-10. Recording measurement mode (pump suction type only)


NOTE

The recording measurement mode is unavailable for the handy aspirator manual draw-in type.

The concentration meter enables automatic measurement and data recording at specified time intervals. While pump is not performed, the concentration meter is put into the power-saving state. The recording measurement can be performed for a few hours up to four days. See the following for the recording measurement flow.




The recording measurement mode allows setting measuring and base gases, recording measurement interval and pump suction time, checking the memory free space and starting recording measurement. This mode can be entered by pressing the POWER switch while holding down the ▼/REC. switch. Every time the ▲ switch is pressed, various menu screens are displayed in turn.



Pump suction time setting

Set a pump suction time during recording measurement.




→ ENTER ⇒P37 Pump suction time setting

Memory free space display

Display a memory free space.

**Recording measurement start**

Start recording measurement.



→ ENTER => P38 Recording measurement start


**DANGER**

- The purpose of the specification targeting anesthetic gas (halothane, isoflurane, sevoflurane, desflurane and enflurane) for measurement is to measure the gas concentration of volatile anesthetic which occurs from anesthetic vaporizer during the manufacturing or inspection. Please do not use it for anesthetic gas concentration in the administration to human and animals nor anesthetic gas measurement for interference gas including laughter gas and aspirated air.
- Before using our product for measurement, please confirm that the measurement gas type is selected correctly.
- In case there are interference gases which are not selected as a measurement gas, you will not get the correct measurement, so please do not use it in that circumstance.

<Measuring Gas Setting>

A measuring gas can be selected.

- Press the ▲/▼ switch and select measuring gas setting from the recording measurement mode menu. The measuring and base gases, range and other information are displayed in turn on the concentration meter (the displayed information varies by the selected measuring gas or range).




- Press the ENTER switch.

NOTE

When there is no need of changing the setting, press the ESC switch to return to the recording measurement mode menu.

- The SPE number (a number allocated to a combination of measuring and base gases, measuring range, etc.) in the upper right section of the screen blinks. It changes to another every time the ▲/▼ switch is pressed.



- Select a desired SPE number and press the ENTER switch to confirm it. The setting is completed when the SPE number stops blinking. When the selection is confirmed by pressing the ENTER switch, the concentration meter returns to the recording measurement mode menu.


<Recording Measurement Interval Setting "REC. INTERVAL">

A recording measurement interval can be selected from 5 sec, 10 sec, 30 sec, 60 sec, 5 min, 10 min, 30 min and 60 min.

- (1) Press the ▲/▼ switch and select recording measurement interval setting from the recording measurement mode menu.



- (2) When the ENTER switch is pressed, the recording measurement interval (numerical value and unit) blinks.

**NOTE**

When there is no need of changing the setting, press the ESC switch to return to the recording measurement mode menu.

- (3) Press the ▲/▼ switch to select a time interval of recording measurement and press the ENTER switch to confirm it.
(Input example: 10 minutes)




- (4) The setting is completed when the numerical value and unit stop blinking.
When the ENTER switch is pressed to confirm the measurement interval, the concentration meter returns to the recording measurement mode menu.


<Pump Suction Time Setting "PUMPING TIME">

A pump suction time can be selected from 10 sec, 30 sec, 60 sec, 300 sec and CONTINUOUS.

- (1) Press the ▲/▼ switch and select pump suction time setting from the recording measurement mode menu.



- (2) When the ENTER switch is pressed, the pump suction time (numerical value and unit) blinks.



NOTE

When there is no need of setting the pump suction time, press the ESC switch to return to the recording measurement mode menu.

- (3) Press the ▲/▼ switch to select a pump suction time and press the ENTER switch to confirm it. (Input example: 60 seconds)



CAUTION


When the concentration meter is used in an environment where measuring gas continuously exists, set the pump suction time setting to "continuous" and the continuous operating time should be less than 2 hours. If the pump suction time setting is set to "continuous" and then used for more than 2 hours, or if the pump suction time setting is not set to "continuous", the symptom that the indication value decreases is caused.

- (4) The setting is completed when the numerical value and unit stop blinking. When the ENTER switch is pressed to confirm the pump suction time, the concentration meter returns to the recording measurement mode menu.

<Recording Measurement Start "RECORDING MEAS.">

Recording measurement can be started.


- (1) Press the ▲/▼ switch and select recording measurement start from the recording measurement mode menu.



- (2) When the ENTER switch is pressed, recording measurement is started. The following screens are displayed in turn on the concentration meter during recording measurement.


<Display until 1 Minute before Next Measurement>

The last recorded measurement result and the time to perform the next measurement (in minutes) are displayed alternately.




<Display from 60 to 2 Seconds before Next Measurement>

The last recorded measurement result and the time to perform the next measurement (in seconds) are displayed alternately.



<Display from 2 to 0 Seconds before Next Measurement>

The last recorded measurement result blinks. The display content will be updated when a new measurement result is saved.



NOTE

If the maximum data amount (256 points) is exceeded, the concentration meter displays "RECORD FULL" and rejects saving of further data. To save data newly, delete the saved data in the display/setting mode (see "4-8. Setup mode" for details).



4-11. How to exit

After measurement, make the concentration meter draw fresh air from GAS IN and discharge the measuring gas remaining inside.

To turn off the power, hold down the POWER switch. The buzzer sounds three times. Hold down the POWER switch until the screen display disappears to turn off the power.



5

Operations and Functions

5-1. CAUTION display

The concentration meter is equipped with a self-diagnosis function. When the caution display appears on the concentration meter, it means that a minor abnormality is found by the self-diagnosis function.

Caution display: Appears when a minor abnormality is found in the concentration meter operation by automatic check function.

Display operation: Displays the caution detail on the screen to notify users of it.

Caution type: Low battery voltage, low contrast, low UV intensity, calibration failure, out-of-specification temperature, out-of-specification pressure


Determine the causes and take appropriate actions.

If the unit has problems and the caution display appears frequently, contact RIKEN KEIKI immediately.


<Display Operation>


LCD display	Provides the normal and caution displays alternately.
-------------	-------------------------------------------------------

Display example1



Display example2



Display example3**NOTE**

- The concentration meter continues measurement with the caution display. However, if the caution display appears, promptly take an appropriate remedial measure to restore the normal condition.
- See "8. Troubleshooting" for caution details and appropriate actions.

5-2. ERROR display

The concentration meter is equipped with a self-diagnosis function. When the error display appears on the concentration meter, it means that a major abnormality that prevents measurement is found by the self-diagnosis function.

Error display: Appears when a major abnormality is found in the concentration meter operation by automatic check function.

Display operation: Displays the error detail on the screen to notify users of it.

Error type: Battery error, contrast error, UV intensity error, setting information error, system error, built-in clock error, optical sensor unit error

Determine the causes and take appropriate actions.

If the unit has problems and the error display appears frequently, contact RIKEN KEIKI immediately.

<Display Operation>

LCD display	Provides the error detail.
Lamp	Blinks
Buzzer	Sounds (be-beep, be-beep...)



Contrast error

Display example

NOTE

- When the error display appears, any mode cannot be entered unless the error is eliminated. When the error display appears, promptly take an appropriate remedial measure.
- See "8. Troubleshooting" for error details and appropriate remedial measure.

6

Maintenance

To maintain the performance of the concentration meter and improve the reliability, perform regular maintenance and check.

6-1. Maintenance intervals and items

- Daily maintenance: Perform maintenance before beginning to work.
- Regular maintenance: Perform maintenance once or more every year to maintain the performance.

Maintenance item	Maintenance content	Daily maintenance	Regular maintenance
Battery level check	Check that the battery level is sufficient.	○	○
Concentration display check	Draw a specified reference gas and check that the displayed concentration value indicates the reference calibration value. If the reading is incorrect, perform reference gas calibration using a reference gas.	○	○
Checking the operation of the main unit	See the pilot indicator to check for abnormalities.	○	○
Checking the operation of the pump (pump suction type only)	See the pump operation status indicator to check for abnormalities.	○	○
Span adjustment	Check the sensitivity using a calibration gas and perform span adjustment as needed.		○

* It is recommended that the sensitivity of the instrument be confirmed periodically (at least once a year) to assume the correct operation. If any problem is found, or if you would like to have it calibrated, please contact any of our agents.

6-2. Calibration

Perform span adjustment of sensors using a calibration gas at least once a year.
Request RIKEN KEIKI to perform span adjustment.

6-3. How to clean

Clean the concentration meter if it becomes extremely dirty. The concentration meter must be turned off while cleaning it. Use a waste cloth to remove dust. Do not use water or organic solvent for cleaning because they may cause malfunctions.



CAUTION

When cleaning the concentration meter, do not splash water over it or use organic solvents such as alcohol and benzene on it. The surface of the concentration meter may be discolored or damaged.

NOTE

When the concentration meter gets wet, water may remain in the buzzer sound opening or clearances.

Drain water as follows:

- (1) Wipe away moisture on the concentration meter thoroughly using a dry towel, cloth, etc.
- (2) While holding the concentration meter firmly, shake it about ten times with the buzzer sound opening facing downward.
- (3) Wipe away moisture coming out from the inside thoroughly using a towel, cloth, etc.
- (4) Place the concentration meter on a dry towel, cloth, etc. and let it stand at normal temperatures.

6-4. Parts replacement

<Replacement of Regular Replacement Parts>

List of recommended regular replacement parts

No.	Item	Part number	Recommended maintenance interval	Recommended replacement interval	Quantity (pieces per unit)	Remarks
1	Pump unit (RP-12)	4181 0610 30	6 months	2 years (*)	1	* Assuming 500 hours of use per year
2	Alkaline dry battery (AA)	2753 3007 80	—	—	3	
3	Lithium ion battery pack (for BUL-8000(F), BUL-8000(F1))	—	—	About 500 cycles of charging and discharging	1	When BUL-8000(F), BUL-8000(F1) is used
4	Rubber cap	4775 5614 50	—	2 years	1	When BUL-8000(F), BUL-8000(F1) is used
5	Handy aspirator	0904 0276 70	—	5 years	1	When the handy aspirator specification type is used

NOTE

The above replacement intervals are recommendation only. The intervals may change depending on the operating conditions. These intervals do not mean the warranty periods either.
The result of the regular maintenance may determine when to replace the parts.

The operation of most of the periodical replacement parts must be checked after replacement by a qualified service engineer.
For the stable operation of the unit and safety, ask a qualified service engineer to take care of replacement of the parts that require operation check. Please contact RIKEN KEIKI.

7

Storage and Disposal

7-1. Procedures to store the concentration meter or leave it for a long time

The concentration meter must be stored under the following environmental conditions.

- In a dark place under the normal temperature and humidity away from direct sunlight
- In a place where gases, solvents or vapors are not present

Store the concentration meter in a shipping carton, if any, in which the product was delivered. Store the concentration meter away from dust, etc. if the shipping carton is not available.



CAUTION

If the concentration meter is not used for a long time, turn on the power at least once every six months and check that the pump draws in air (about three minutes). The concentration meter, when not activated for a long time, may cease to work because of hardening of the grease in the pump motor.

NOTE

- If the concentration meter with a lithium ion battery unit is not used for a long time, it is recommended to store it after discharging the batteries until the battery level icon shows one battery mark or so. If the concentration meter is stored with the batteries fully charged, the batteries get deteriorated more quickly and may have shorter life.
- If the concentration meter with a dry battery unit is not used for a long time, store it after removing the batteries. Battery leaks may result in fire or injury. If the concentration meter is not used for a short time, store it without removing the batteries.

7-2. Procedures to use the concentration meter again



CAUTION

When using a stopped or stored concentration meter again, never fail to perform a calibration. For information on readjustment including calibration, please contact RIKEN KEIKI.

7-3. Disposal of products

When the concentration meter is disposed of, it must be treated properly as an industrial waste in accordance with the local regulations.



WARNING

- Dispose of the batteries in accordance with procedure specified by the local authority.
- When disposing of the concentration meter in EU member states, sort the batteries as specified. Handle the removed batteries according to the classified refuse collection system and recycling system based on the regulations of EU member states.

Removing batteries

See Section 4-2 "Preparation for start-up" and take out the batteries.

When BUL-8000(F), BUL-8000(F1) is used

Model	Type
BUL-8000(F) BUL-8000(F1)	Lithium ion battery

NOTE

- BUL-8000(F), BUL-8000(F1) (option) contains batteries.
- Crossed-out recycle dustbin mark



This symbol mark is indicated on the products which contain the batteries which fall under EU Battery Directive 2006/66/EC. Such batteries need to be disposed of as specified by the latest Directive. This symbol mark indicates that the batteries need to be separated from the ordinary waste and disposed of appropriately.

8

Troubleshooting

The troubleshooting does not explain the causes of all the malfunctions which occur on the concentration meter. This simply helps to find the causes of malfunctions which frequently occur. If the concentration meter shows a symptom which is not explained in this manual, or still has malfunctions even though remedial actions are taken, please contact our sales department.

<Troubles on the Unit>

Symptoms	Causes	Actions
<u>The power cannot be turned on.</u>	The battery level is too low.	Dry battery unit: Turn off the power and replace all the three dry batteries with new ones in a non-hazardous area. Lithium ion battery unit: Turn off the power and charge the batteries in a non-hazardous area.
	The POWER switch was not pressed long enough.	For power-on, keep the POWER switch pressed until a beep is heard.
	Improper installation of the battery unit	Check whether the battery unit is properly attached to the main unit.
<u>Abnormal operations</u>	Disturbances by sudden static electricity noise, etc.	Turn off and restart the concentration meter.
<u>Key operations are disabled.</u>	Disturbances by sudden static electricity noise, etc.	Turn off the power, and remove the battery unit and install it again in a non-hazardous area and then turn on the power to perform operations.
<u>Low battery voltage caution is displayed.</u> (CAUTION) LOW BATTERY	The battery level is low.	Dry battery unit: Turn off the power and replace the dry batteries with new ones in a non-hazardous area.
		Lithium ion battery unit: Turn off the power and charge the batteries in a non-hazardous area.
<u>Low contrast caution is displayed.</u> (CAUTION) LOW CONTRAST	The contrast of interferometric sensor has been decreased due to contamination.	Replacement or repair of the interferometric sensor is recommended. Request RIKEN KEIKI for the replacement or repair.
<u>Low UV intensity caution is displayed.</u> (CAUTION) LOW BRIGHTNESS	The UV intensity of interferometric sensor has been dropped.	Replacement or repair of the interferometric sensor is recommended. Request RIKEN KEIKI for the replacement or repair.
	Condensation occurred inside the product (light source sensor).	Draw dry air to dry the sensor.

<u>Reference calibration caution is displayed.</u> (CAUTION) CHECK REF. CAL	Zero drift may have occurred.	Perform reference gas calibration using a specified reference gas (see the measuring gas specifications for the specified reference gas).
	Condensation occurred inside the product (light source sensor).	Draw dry air to dry the sensor.
<u>Out-of-specification temperature caution is displayed.</u> (CAUTION) OUT of SPEC. TEMP	The built-in temperature sensor detected a temperature exceeding the specified range.	Use the concentration meter within the specified temperature range -20 - +50°C.
<u>Out-of-specification pressure caution is displayed.</u> (CAUTION) OUT of SPEC. PRES	The built-in pressure sensor detected an abnormal pressure.	Use the concentration meter under the atmospheric pressure approx.63-115kPa.
<u>Built-in clock error is displayed.</u> (ERROR) CLOCK	An abnormal time setting for the internal clock was detected.	Make a setting of date/time. If the symptom like this recurs frequently, contact RIKEN KEIKI.
<u>Battery error is displayed.</u> (ERROR) LOW BATTERY	The battery level is too low to perform measurement.	Dry battery unit: Turn off the power and replace the dry batteries with new ones in a non-hazardous area.
		Lithium ion battery unit: Turn off the power and charge the batteries in a non-hazardous area.
<u>Contrast error is displayed.</u> (ERROR) LOW BRIGHTNESS	The contrast of interferometric sensor has been decreased so much due to contamination that measurement cannot be performed.	Request RIKEN KEIKI for the replacement or repair of interferometric sensor.
<u>UV intensity error is displayed.</u> (ERROR) LOW BRIGHTNESS	An abnormality occurred in the system.	Request RIKEN KEIKI for the replacement or repair of interferometric sensor.
<u>Optical sensor unit error</u> (ERROR) OPTOCAL UNIT	An abnormality occurred in communication signals from the optical sensor unit.	Turn off and restart the concentration meter. If the symptom like this recurs frequently, the interferometric sensor needs to be repaired. Request RIKEN KEIKI for the repair.
<u>Setting information error is displayed.</u> (ERROR) SETTING	The data set in the setup mode is damaged.	Check the setting in the setup mode. If the setting disagrees with the displayed content, set the data again.
<u>System error is displayed.</u> (ERROR) SYSTEM	An abnormality occurred in the system.	Request the dealer or Riken Keiki local representative for repair.
<u>The batteries cannot be charged.</u> (Rechargeable battery unit only)	The charger is not connected properly.	Connect the AC plug and DC plug of the AC powered charger properly.
	A charging circuit abnormality occurred.	Request the dealer or Riken Keiki local representative for repair.
	The batteries have been fully charged.	When fully charged batteries are charged again, the charging indicator lamp does not go on.

<Troubles in Reading>

Symptoms	Causes	Actions
<u>Incorrect reading</u>	Drifting of sensor output	Perform reference gas calibration.
	Measuring and base gases were not selected correctly.	Select measuring and base gases correctly.
	Presence of interference gas	If an interference gas (other than measuring and base gases) is included, correct measurement cannot be performed by the concentration meter. Remove the interference gas and perform measurement again.
	GAS IN/GAS OUT is not at atmospheric pressure.	The concentration meter can perform correct measurement under the atmospheric pressure only. Keep GAS IN/GAS OUT at the atmospheric pressure and then perform measurement again.
	Bended or clogged suction tube or exhaust tube	Fix the defective parts.
	Condensation is formed inside the suction tube.	Fix the defective parts.

9

Product Specifications

9-1. List of specifications

Model	FI-8000	
Measuring principle	Optical interferometric type	
Measuring gases	See *1 below	
Reading accuracy	Depending on the measuring gas. See *2 below	
Sampling method	Automatic draw-in by built-in pump	Manual draw-in by handy aspirator
Self-diagnosis function	Low battery voltage, low UV intensity, low contrast, abnormal pressure, abnormal temperature	
Display	LCD digital display (7-segment numeric display + symbol + 20-segment character display x 2 lines)	
Displays	Gas concentration, gas name, measuring range, battery level	
External output	IrDA (for data logger)	
Functions	Data logger, pressure correction, temperature correction	
Power supply	Dry battery unit (AA alkaline dry battery x 3)【BUD-8000(F)】 or lithium ion battery unit 【BUL-8000(F), BUL-8000(F1)】	
Continuous operating time	BUD-8000(F) : 12 hours or more (25°C, no alarm, and no lighting) BUL-8000(F), BUL-8000(F1) : 18 hours or more (25°C, no alarm, no lighting, and battery fully charged)	BUD-8000(F) : 16 hours or more (25°C, no alarm, and no lighting) BUL-8000(F), BUL-8000(F1) : 24 hours or more (25°C, no alarm, no lighting, and battery fully charged)
Use temperature/humidity range	Temperature range: -20 - +50°C (at a constant condition), humidity range: Below 95% RH (Non-condensing)	
Protection class	Compliant with IP67	
Explosion-proof structure	Intrinsically safe explosion-proof structure	
Explosion-proof class	Ex ia IIC T4(Japan Ex) II1G Ex ia IIC T4 Ga (ATEX/UKEX) Ex ia IIC T4 Ga (IECEX)	
External dimensions	Approx. 154 (W) x 127 (H) x 81 (D) (mm)	
Weight	Approx. 1.1 kg (BUD-8000(F) included) Approx. 1.2 kg (BUL-8000(F) or BUL-8000(F1) included)	

* Specifications subject to changes without notice.

*1 See the measuring gas specifications for measuring gases, range, reading accuracy, etc.
See "Measuring Gas Specifications by Type" at the end of this manual for the standard lineup types.
See the separate specification sheet for measuring the gases not included in "Measuring Gas Specifications by Type".

- *2 Reading accuracy is calculated with the formula below.
(The calculated value is the reading accuracy right after the reference gas calibration.)

$$\text{Reading Accuracy} = \pm(\text{Reading} - \text{REF CAL Value}) \times 0.03$$

(Example)

Measuring gas : Halothane
Base gas : Oxygen
Measuring range : 0.00-6.00vol%
REF CAL value : 1.57vol% (See Page 52 "Measuring gas specifications by TYPE")

If the Reading is 4.23vol% with the gas specification mentioned above

$$\begin{aligned} \text{Reading accuracy} &: \pm(\text{Reading} - \text{REF CAL value}) \times 0.03 \\ &= \pm(4.23 - 1.57) \times 0.03 \\ &= \pm 0.0798 \end{aligned}$$

9-2. List of accessories

Standard accessories	<ul style="list-style-type: none"> • Dry battery unit (BUD-8000(F)) or lithium ion battery unit (BUL-8000(F), FI-8000(F1)): 1 • Alkaline dry battery: 3 (for Dry battery unit) • AC powered charger: 1 (for lithium ion battery unit) • Gas sampling hose: 1 • Shoulder strap: 1 • Handy aspirator: 1 (manual draw-in type only) • Absorbing tube (contains calcium chloride) and absorbing tube fixing belt (anesthetic gas specification only) • Operating manual • Measuring gas specifications (attached when measuring gases are not included in "Measuring Gas Specifications by Type" at the end of this manual) • Product warranty
Optional accessories	<ul style="list-style-type: none"> • Dry battery unit (BUD-8000(F)) • Alkaline dry battery • Lithium ion battery unit (BUL-8000(F), FI-8000(F1)) • AC powered charger

- See "Measuring Gas Specifications by Type" at the end of this manual for the FI-8000 specification.

10

Definition of Terms

vol%	Gas concentration indicated in the unit of one-hundredth of the volume
LEL	An acronym for Lower Explosive Limit. LEL refers to the lowest concentration of a combustible gas in air capable of causing explosion when ignited.
g/m ³	A unit used to represent the mass of concentration measurement target gas contained in 1 m ³ .
Measuring gas	Of the draw-in gases, the ones targeted for concentration measurement.
Base gas	Of the draw-in gases, the ones other than measuring gases.
Reference gas	A gas used as a reference of refractive index in performing measurement (see the measuring gas specifications).
Reference gas calibration value	A value that should be read in measuring a reference gas (see the measuring gas specifications).

11


Detection Principle

The refractive index of gases is determined by the types of composing gases and the mix ratio. When a mixed gas consists of two different gases and the types are known, the mix ratio (concentration) can be obtained by measuring the refractive index.

The optical interferometric sensor used for the concentration meter forms an "interference fringe" that moves in proportion to changes in refractive index on the image sensor. Then the interference fringe is captured by the image sensor and converted into a refractive index after calculating the move amount of interference fringes with a high degree of accuracy through the phase analysis processing.

The "concentration" display of various mixed gases is enabled by inputting the data such as type and refractive index of "measuring gas" and "base gas" that compose a mixed gas to the "refractive index" calculated with high accuracy.

The sensitivity of optical interferometric sensor depends on the length of the chamber that flows gases. Because the chamber length is physically unchangeable, high accuracy is maintained over a long period of time.



Schematic view of optical interferometric sensor



FI-8000

Measuring Gas Specifications by Type

TYPE □ - 24 - 50	Anesthetic gas
TYPE □ - 48 - 52	Fumigation gas

NOTE

- Measuring gases vary by the type of the concentration meter. The type of FI-8000 can be checked with the nameplate attached to the side of the main unit. (See the right figure for the nameplate location.)
- How to identify the type.



- Measuring gases, range, reading accuracy, etc. are included in the measuring gas specifications. When the anesthetic or fumigation gas specification is used, see "Measuring Gas Specifications by Type" at the end of this manual. When the customized specification is used, see the separate measuring gas specifications.

[Anesthetic Gas]

TYPE P-24-50	Anesthetic gas and pump specification
TYPE A-24-50	Anesthetic gas and handy aspirator specification

Selectable gases and measuring ranges

	Measuring gas type (Display characters)	Measuring range (Minimum digit)	Reference gas (REF CAL value)	Drift amount*
1	Halothane in O2 (HALOTHANE in O2)	0.00 - 6.00 vol% (0.01 vol%)	AIR (1.57 vol%)	±0.11 vol%
2	Isoflurane in O2 (ISOFLURANE in O2)	0.00 - 8.00 vol% (0.01 vol%)	AIR (1.65 vol%)	±0.11 vol%
3	Sevoflurane in O2 (SEVOFLURANE in O2)	0.00 - 10.00 vol% (0.01 vol%)	AIR (1.70 vol%)	±0.12 vol%
4	Desflurane in O2 (DESFLURANE in O2)	0.00 - 20.00 vol% (0.02 vol%)	AIR (2.10 vol%)	±0.14 vol%
5	Halothane in AIR (HALOTHANE in AIR)	0.00 - 6.00 vol% (0.01 vol%)	AIR (0.00 vol%)	±0.11 vol%
6	Isoflurane in AIR (ISOFLURANE in AIR)	0.00 - 8.00 vol% (0.01 vol%)	AIR (0.00 vol%)	±0.12 vol%
7	Sevoflurane in AIR (SEVOFLURANE in AIR)	0.00 - 10.00 vol% (0.01 vol%)	AIR (0.00 vol%)	±0.12 vol%
8	Desflurane in AIR (DESFLURANE in AIR)	0.00 - 20.00 vol% (0.02 vol%)	AIR (0.00 vol%)	±0.16 vol%

Interferometric chamber length: 24 mm

Reading accuracy: $\pm(\text{Reading} - \text{REF CAL value}) \times 0.03$

REF CAL value:	A value that should be read in measuring a reference gas
Drift amount:	Drift of reading that may be caused by $\pm 10^\circ\text{C}$ change in temperature
Reading accuracy	The accuracy right after reference gas calibration (REF CAL)

Special caution

- *1) Because the substance does not volatilize easily, the upper concentration in the measuring range may not be reached depending on the temperature or pressure.
- *2) The purpose of this specification is to measure the gas concentration of volatile anesthetic which occurs from anesthetic vaporizer during the manufacturing or inspection. Please do not use it for anesthetic gas concentration in the administration to human and animals nor anesthetic gas measurement for interference gas including laughter gas and aspirated air.
- *3) Before using our product for measurement, please confirm that the measurement gas type is selected correctly.
- *4) In case there are interference gases which are not selected as a measurement gas, you will not get the correct measurement, so please do not use it in that circumstance.

[Fumigation Gas]

TYPE P-48-52	Fumigation gas and pump specification
TYPE A-48-52	Fumigation gas and handy aspirator specification

Selectable gases and measuring ranges

	Measuring gas type (Display characters)	Measuring range (Minimum digit)	Reference gas (REF CAL value)	Drift amount*
1	Methyl bromide in AIR (CH ₃ Br in AIR)	0 - 200 g/m ³ (0.2 g/m ³)	AIR (0.0 g/m ³)	±5.0 g/m ³
2	Methyl iodide in AIR (CH ₃ I in AIR)	0 - 200 g/m ³ (0.2 g/m ³)	AIR (0.0 g/m ³)	±5.0 g/m ³
3	Sulfuryl fluoride in AIR (SO ₂ F ₂ in AIR)	0 - 200 g/m ³ (0.5g/m ³)	AIR (0.0 g/m ³)	±7.0 g/m ³
4	Propylene oxide in AIR (PO in AIR)	0.000 - 10.000 vol% (0.005 vol%)	AIR (0.000 vol%)	±0.100 vol%
5	Methyl bromide in AIR (CH ₃ Br in AIR)	0.000 - 5.000 vol% (0.005 vol%)	AIR (0.000 vol%)	±0.110 vol%
6	Phosphine in AIR (PH ₃ in AIR)	0.0 - 50.0 g/m ³ (0.1g/m ³)	AIR (0.0 g/m ³)	±2.1 g/m ³
7	Hydrogen Cyanide in AIR (HCN in AIR)	0.0 - 200.0 g/m ³ (0.1g/m ³)	AIR (0.0 g/m ³)	±5.5 g/m ³
8				

Interferometric chamber length: 48 mm

Reading accuracy: $\pm(\text{Reading} - \text{REF CAL value}) \times 0.03$

REF CAL value: A value that should be read in measuring a reference gas
 Drift amount: Drift of reading that may be caused by $\pm 10^{\circ}\text{C}$ change in temperature
 Reading accuracy: The accuracy right after reference gas calibration (REF CAL)

Special caution

*1) Measuring gases are highly toxic.
 Carefully handle the gases discharged from the gas outlet (GAS OUT) and take sufficient safety measures.



EU-Declaration of Conformity

Document No.: 320CE22072



We, RIKEN KEIKI Co., Ltd. 2-7-6, Azusawa, Itabashi-ku, Tokyo, 174-8744 Japan declare under our sole responsibility that the following product conforms to all the relevant provisions.


Product Name: Optical Interferometric Gas Concentration Meter
Model: FI-8000

Council Directives		Applicable Standards
2014/30/EU	EMC Directive	EN 50270:2015
2014/34/EU	ATEX Directive	EN IEC 60079-0:2018 EN 60079-11:2012
2011/65/EU ^[1]	RoHS Directive	EN IEC 63000:2018

^[1]Including substances added by Commission Delegated Directive (EU) 2015/863

EU-Type examination Certificate No.	Presafe 14 ATEX 5711X
Notified Body for ATEX	DNV Product Assurance AS (NB 2460) Veritasveien 1 1363 Høvik Norway
Auditing Organization for ATEX	DNV Product Assurance AS (NB 2460) Veritasveien 1 1363 Høvik Norway

The marking of the product shall include the following:

 II 1 G Ex ia IIC T4 Ga

Place: Tokyo, Japan

Date: Jun. 29, 2022

Takakura Toshiyuki
General manager
Quality Control Center



UK-Declaration of Conformity

Document No.: 320UK22039



We, RIKEN KEIKI Co., Ltd. 2-7-6, Azusawa, Itabashi-ku, Tokyo, 174-8744, Japan declare under our sole responsibility that the following product conforms to all the relevant provisions.

Product Name: Optical Interferometric Gas Concentration Meter
Model: FI-8000

Regulations	UK designated Standards
Electromagnetic Compatibility Regulations 2016 (S.I. 2016/1091)	BS EN 50270:2015
The Equipment and Protective Systems Intended for Use in Potentially Explosive Atmospheres Regulations 2016 (S.I. 2016/1107) (UKEX)	BS EN IEC 60079-0:2018 BS EN 60079-11:2012
The Restriction of the Use of Certain Hazardous Substances in Electrical and Electronic Equipment Regulations 2012 (S.I. 2012/3032)	BS EN IEC 63000:2018

UK-Type examination Certificate No.

DNV 22 UKEX 22578X

Approved Body for UKEX

DNV Business Assurance UK Ltd (AB8501)
4th Floor Vivo Building, 30 Stamford Street,
London SE1 9LQ, United Kingdom

Auditing Organization for UKEX

DNV Business Assurance UK Ltd (AB8501)
4th Floor Vivo Building, 30 Stamford Street,
London SE1 9LQ, United Kingdom

The marking of the product shall include the following:

 II 1 G Ex ia IIC T4 Ga -20°C≤Ta≤+50°C

Place: Tokyo, Japan

Date: Nov. 18, 2022

Takakura Toshiyuki
General manager
Quality Control Center