

Error code list

Model: SD-D58 series

Symptom/display	FAULT lamp	Cause	Corrective action
Sensor abnormalities E-1	●	The sensor is not connected or improperly connected.	Check if the cable is securely fastened to the terminal plate.
		Zero drift caused by environmental changes or aging deterioration becomes out of the range of zero follower.	Perform the zero adjustment. If the symptom persists after the zero adjustment, replace the sensor with a new one.
		Faults of the sensor	Replace the sensor with a new one.
Low flow rate abnormality E-5	●	The flow rate is low.	The possible causes are deterioration or clogging of the pump or clogging of the tube. Check the flow rate.
		Faults of the flow sensor	Replace the sensor with a new one.
System abnormalities E-9	●	Abnormalities of ROM, RAM, or EEPROM inside of the detector head	Please contact distributor.