RIKEN KEIKI

PT1E-1083

INDICATOR / ALARM UNIT
MODEL RM－5000 SERIES
OPTION MANUAL
（ALARM PATTERN）

RIKEN KEIKI Co.,Ltd.

2-7-6 Azusawa, Itabashi-ku, Tokyo, 174-8744, Japan
Phone : +81-3-3966-1113
Fax : +81-3-3558-9110
E-mail : intdept@rikenkeiki.co.jp
Web site : https://www.rikenkeiki.co.jp/

In the beginning

This manual refers to the option of alarm patterns operation method, and work explanation of RM-5000 series.
For this detailed handling and operation, refer to each separate instruction manual.
For this correct use, read this manual well together with the separate instruction manual and then after understanding this content, it is kindly requested to operate this instrument.
Now for improvement and modification of this product, it shall be subject to change without notice and it is prohibited to strictly duplicate or copy a part or all of this manual without permission.

Contents

☐ 1. Gas alarm(H-HH, self-latching)/Fault alarm(auto-reset) ・・・・・・・・・・・・・・・・・・・・・・3

☐ 2. Gas alarm(H-HH, auto-reset)/Fault alarm(auto-reset)・・・・・・・・・・・・・・・・・・・・・・・4

☐ 3. Gas alarm(H-HH, lock-in)/Fault alarm(auto-reset) ・・・・・・・・・・・・・・・・・・・・・・・・5

☐ 4. Gas alarm(L-LL, self-latching)/Fault alarm(auto-reset) ・・・・・・・・・・・・・・・・・・・・・6

☐ 5. Gas alarm(L-LL, auto-reset)/Fault alarm(auto-reset)・・・・・・・・・・・・・・・・・・・・・・・7

☐ 6. Gas alarm(L-LL, lock-in)/Fault alarm(auto-reset) ・・・・・・・・・・・・・・・・・・・・・・・・8

☐ 7. Gas alarm(L-H, self-latching)/Fault alarm(auto-reset)・・・・・・・・・・・・・・・・・・・・・・9

☐ 8. Gas alarm(L-H, auto-reset)/Fault alarm(auto-reset) ・・・・・・・・・・・・・・・・・・・・・・10

☐ 9. Gas alarm(L-H, lock-in)/Fault alarm(auto-reset)・・・・・・・・・・・・・・・・・・・・・・・・11

1. Gas alarm(H-HH, self-latching)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

2. Gas alarm(H-HH, auto-reset)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

3. Gas alarm(H-HH, lock-in)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

4. Gas alarm(L-LL, self-latching)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

5. Gas alarm(L-LL, auto-reset)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

6. Gas alarm(L-LL, lock-in)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

7. Gas alarm(L-H, self-latching)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)

8. Gas alarm(L-H, auto-reset)/Fault alarm(auto-reset)





■ : Acting □ : Not acting ("Acting" is optional)

9. Gas alarm(L-H, lock-in)/Fault alarm(auto-reset)



■ : Acting □ : Not acting ("Acting" is optional)